

## PART NUMBER WTW-IPC-2-1

This Wire Termination tool can be used to terminate wires for Zierick Part Number IPC-2- $\hbox{1-T (Surface Mount Insulation Piercing Crimp Terminal for Coaxial Cable) in low volume} \\$ or in the field (Figure 1).

## Crimping Instructions:

- Place stripped wire (coax cable needs the outer jacket and braid stripped approximately 0.250"(6.35mm)) into the IPC-2-1-T Coaxial Terminal.
   Place the board mounted terminal and cable into the Wire Termination Tool as
- shown in the picture (Figure 2).

  Squeeze the Tool handle to push the terminal down until hand tool releases.
- If greater activation force is needed, adjust by loosening Philips screw and turning sprocket to proper setting (Figure 3).

## **Crimp Hand Tool Part Number:**

WTW-IPC-2-1



Figure 1: WTW-IPC-2-1 Termination



Figure 2: Wire Placement in Tool



Figure 3: Force Adjustment Sprocket