### **Product sheet**

## **Output connector**



Contacts: 16, Cable plug connector, Product


shieldable, right-turning (the pin and socket insert counter-rotate in right and

left turning models)


Pole

M23 Power Series 623 Article number 99 4623 00 16





Area



You can find the assembly instruction on the next page.

# Technical data

### **Common values**

Connector Design Connector locking system Termination Wire gauge (mm) Wire gauge (AWG) Cable outlet Upper temperature Lower temperature

Cable plug connector screw Solder 1.00 mm<sup>2</sup> 18 6 - 10 mm 125 ℃ -20 °C

### **Electrical values**

Rated voltage 150 V Rated impulse voltage 1500 V Pollution degree 3 Overvoltage category П Material group Ш Rated current (40°C) 8 A Volume resistivity  $\leq 3 \text{ m}\Omega$ EMV compliance shielded Degree of protection IP67 > 50 mating cycles Mechanical operation

### Material

Material of contact CuZn (Brass) Au (Gold) Contact plating PBT/PA66 Material of contact body Material of housing CuZn (Brass nickel-plated)

### **Product sheet**

## **Output connector**




Contacts: 16, Cable plug connector, Product shieldable, right-turning (the pin and

socket insert counter-rotate in right and left turning models)

Pole

Area Article number M23 Power Series 623 99 4623 00 16

## Installation instructions / Mounting cutout



- Adapter Pos. 1, Überwurfmutter Pos. 2, Dichtelement Pos. 4 mit Dichtring Pos. 3 auf das Kabel
- schieben.

  Kabel-Außenmantel 23 mm abisolieren.

  Detail A: Schirmgeflecht 90° hochstellen, Schirmhülse Pos. 5A über die Folie bzw. Baurnwollgeflecht jedoch unter das Schirmgeflecht mit drehender Bewegung schieben. Schirmgeflecht bündig mit Außendurchmesser Schirmhülse Pos. 5A abschneiden.
- Folie, Füller und innere Isolierungen abschneiden.
   Litzen 3,5 mm abisolieren, verdrillen und verzinnen.
- Litzen an Kontakte löten, crimpen oder schrauben.
- Distanzhülse Pos. 6 einfügen.
   Einsatz Pos. 7 und Distanzhülse Pos. 6 in Einsatzhülse Pos. 8 einführen. Hierbei ist zu beachten, del die gewünschte Kodiemut des Einsatzes Pos. 7 in den Kodiersteg eingeführt wird.

  Kabel mit Schirm- und Dichteinheit eindrücken.

  Adapter Pos. 1 Festschrauben auf Anschlog.

Anzugsdrehmoment für Klemmschraube Kontakteinsatz Pos. 7 mit Schraubkontakten beachten:

• max. 0,1 Nm für Schraubkontakte Steckdurchmesser 1 mm

- max. 0,2 Nm für Schraubkontakte Steckdurchmesser 2 mm

- Push the adapter (1), the coupling nut (2) and the sealing ring (4) with the gasket (3) onto the cable.
- the cable.

  Strip the cable cooling by 23 mm.

  Detail X: Push back the shielding braid so it stands out at 90°. With a rotating motion, push the shielding braid (5A) over the fail or catton braid and under the shielding braid. Cut the shielding braid and flush with the external diameter of the shielded sleeve (5A).
- Trim foil, filler and inner insulation.
  Strip the single wires by 3.5 mm, twist and tin.
- Solder, crimp or screw the single wires to the contacts.
- Insert the distance shell (6).
  Guide the insert (7) and distance shell (6) into the insert sleeve (8), mind that the desired order insert (7) and assume size (0) into the insert size coding groove of the insert (7) is pushed into the coding bar.
   Press in the cable with the shield and sealing unit.
- Screw the adapter (1) as tight as possible.

Please note: torque for clamping screw for contact insert (7) with screw contacts:

• max. 0.1 Nm for screw contacts with mating dia. 1 mm

- max. 0.2 Nm for screw contacts with mating dia. 2 mm

Date: 2015-06-04 - Page 2 of 2