Product sheet

Subminiature connector





Product Pole Contacts: 3, male panel mount connector

3

Area Article number Micro Push-Pull IP67 Series 420 09 4707 00 03

Illustration





You can find the item description and assembly instruction on the next page.

Technical data

Common values

Connector Design Connector locking system Termination Wire gauge (mm) Wire gauge (AWG) Upper temperature

Wire gauge (AWG)
Upper temperature
Lower temperature

Cable data

material housing Insulation single lead Single lead structure Conductor resistance Male panel mount connector Micro Push-Pull Solder 0.14 mm² 26 80 °C

-

-40 °C

Rated voltage Rated impulse voltage

Pollution degree Overvoltage category Material group

Material group Rated current (40°C) Volume resistivity EMV compliance

Degree of protection Mechanical operation

Electrical values

125 V 1500 V 2 II II 1 A ≤ 8 mΩ not shieldable IP67 > 1000 mating cycles

Material

Material of contact Contact plating Material of contact body Material of housing CuZn (Brass) Au (Gold) PA

Contacts: 3, male panel mount connector


Product sheet


Subminiature connector



Product Pole Contacts: 3, male panel mount connector

Area Article number Micro Push-Pull IP67 Series 420 09 4707 00 03





Product sheet

Subminiature connector



Product Contacts: 3, male panel mount connector Pole

Area Article number

Micro Push-Pull IP67 Series 420 09 4707 00 03

Installation instructions / Mounting cutout

- 1. Abmanteln auf L = 9mm. Ummantelung abstreifen.
- Ummantelung absterlen.

 2. Dichtring inkenmvorrichtung montieren.
 Druckschraube und Verriegelungseinheit auf Kabel
 auffädeln.

 3. Litzen abisolieren (I = 3mm) und verzinnen.

- Litzen absolieren (i 3mm) und verzinnen.
 Einsätze anlöten.
 Verriegelungseinheit orientiert, Pfeilrichtung beachten, aufschieben und aufschrauben.
 Druckschraube aufschieben und vor dem Festziehen
- an Schlüsselfläche kontern.

(Bei Demontage zuerst Druckschraube öffnen)

- Strip to 9mm length and remove cable jacket.
 Mount sealing ring to clamp device to cable
- Bead pressing screw and clamp device.

 3. Strip the insulation off the wires (I = 3mm)
- and tin them. Solder wires to solder cups.
- Soluter whee so soluter cups.
 Align locking unit, bear in mind direction of arrow, push forward and screw tightly.
 Push pressing screw forward and secure them at flats.

(Before unmounting first open pressing screw.)

